## **QUESTIONNAIRE**

Please take a few moments to answer our questions. They will help us develop new products for the future.			
1	Do you own any other air movement products?  Air conditioner Table fan Ceiling fan Tower fan Pedestal fan Floor fan Humidifier Air purifier No Fan heater Other, please specify	6	Do you own other Dyson products?  Vacuum cleaner  Handheld  Fan  No
2	Which brand of fan are you replacing or adding to?  Dyson Heller Mistral Coral Breeze Dimplex Sunbeam IXL Don't know Other, please specify	7	Where do you intend to use the Dyson fan? (Please tick as many boxes as applicable)  Bedroom Lounge Dining room Kitchen Study Other, please specify
3	Why did you choose to buy a Dyson fan? (Please rate each statement on a scale of 1 to 5, 1 being the least important and 5 the most important).  1 2 3 4 5  Dyson reputation Smooth, powerful airflow Previous experience of Dyson Safety Features Easy to clean Price/special offer Store staff recommendation Latest model/technology Aesthetics Friend/family recommendation	9	What is your household income?  Less than \$45,000  Between \$45,000 - \$75,000  Between \$75,000 - \$100,000  Over \$100,000  To which age group do you belong?  16 - 24  25 - 34  35 - 44  45 - 54  55 - 64  65+
4	Where did you first hear about Dyson fans? From friends and family From a TV/magazine/internet advert Saw it in a store catalogue Saw it in a store Recommended by salesperson Online blog/review article Email from Dyson		Would you recommend a Dyson fan to your friends and family?  Yes No  No  Do you have children?  Under 5 years 5+ years No children Children no longer at home Pregnant
5	Where did you look for additional information?  Dyson website Online reviews and forums Retail staff Retail catalogue No additional research was done	12	Which best describes your home?  Up to 2 beds 3-4 beds  More than 4 beds

THANK YOU FOR YOUR TIME

#### **BATTERY REPLACEMENT**

- Switch 'OFF' and unplug the machine before replacing the battery.
- Do not install backwards or short circuit the battery.
- Do not attempt to dismantle, recharge or put the battery in a fire. Do not directly handle a leaking battery.
- Carefully follow all instructions and warnings provided with the new battery.

#### 2 YEAR DYSON GUARANTEE

#### TERMS AND CONDITIONS

Terms and conditions of your Dyson 2 year guarantee

- The guarantee becomes effective from the date of purchase
- All work will be carried out by Dyson Appliances (Aust) Pty Ltd, Avery Robinson Ltd (NZ), Singapore's authorised agent - Service @Home Pte Ltd. Indonesia's authorised agent- PT Higienis Indonesia or their authorised agents.
- Any parts replaced will become the property of Dyson Appliances (Aust) Pty Ltd., Avery Robinson Ltd (NZ), Dyson Singapore Pte Ltd., PT Higienis Indonesia.
- The repair and replacement of the fan under guarantee will not extend the
- The guarantee provides benefits which are additional to and do not affect your statutory rights as a consumer. You must provide proof of purchase before any work can be carried out on your fan. Without this proof, any work carried out will be chargeable. Please keep your receipt.

#### WHAT IS COVERED

The repair and replacement of the fan if it is found to be defective due to faulty materials, workmanship or function within 2 years of purchase (if any part is no longer available or out of manufacture, Dyson will replace it with a functional

#### WHAT IS NOT COVERED

Dyson shall not be liable for costs of repair or replacement of a product incurred  $% \left( 1\right) =\left( 1\right) \left( 1\right$ as a result of:

- Normal wear and tear.
- Accidental damage, faults caused by negligent use or care, neglect, careless operation or handling of the fan which is not in accordance with this manual.
- Damage as a result of use not in accordance with the rating plate.
- Blockages please refer overleaf for details on how to unblock the fan. Use of parts and accessories other than those produced or recommended by
- Damage from external sources such as transit, weather, electrical outages or
- Repairs or alterations carried out by parties other than Dyson or its authorised
- Failures caused by circumstances outside Dyson's control.

If you are in doubt as to what is covered by your guarantee, please call the

Dyson Customer Care Helpline on: New Zealand 0800 397 667

Singapore 7000 435 7546 Indonesia 021 707 39766

Remember: Always disconnect plug from mains before inspecting for problems. If the fan will not operate, first check the mains socket has electricity supply and that the plug is properly inserted into the socket.

#### **REGISTERING YOUR GUARANTEE**

To help us ensure you receive prompt and efficient service, please register as a Dyson fan owner. There are three ways to do this:

- Online (Australia only) at www.dyson.com.au/register
- By calling the Dyson Customer Care Helpline.
- By completing and returning the enclosed form to us by mail.

This will confirm ownership of your Dyson fan in the event of an insurance loss, and enable us to contact you if necessary.

#### DYSON CUSTOMER CARE

If you have a query about your Dyson fan call the Dyson Customer Care Helpline and quote your serial number, or contact us via the Dyson website. The serial number can be found on the base of the product. Most queries can be solved over the phone by one of our Dyson Customer Care Helpline staff.

If your Dyson fan needs servicing, call the Dyson Customer Care Helpline to discuss the available options

#### DYSON CUSTOMER CARE DETAILS

If there are any queries, please call the Dyson Customer Care Helpline AU: 1800 239 766

(Mon-Fri 8:00am to 6:00pm EST, Sat-Sun 8:30am to 4:00pm EST) www.dvson.com.au

NZ: 0800 397 667 (Mon-Fri 8:30am to 5:00pm) www.dyson.co.nz

SG: 7000 435 7546 (Mon-Fri 9:00am to 6:00pm)

www.dyson.com.sg ID: 021 707 39766 (Mon-Fri 9:00am to 5:00pm) www.dvson.co.id

#### **ABOUT YOUR PRIVACY**

Dyson may use your information provided for future marketing and research purposes (including sending commercial electronic messages) and may disclose it to third parties for the purposes of providing the services you have requested, or to our business partners or professional advisers. If you wish to access your personal information or see our full privacy policy, please contact us at customercare@dyson.com.au

#### **DISPOSAL INFORMATION**

Dyson products are made from high grade recyclable materials. Please dispose of this product responsibly and recycle where possible.

The battery should be removed from the product before it is disposed of Dispose or recycle the battery in accordance with local ordinances or

When your Dyson reaches the end of its life, we are responsible for it's safe disposal. You can send your old Dyson back to us (at our cost) and we will organise for it to be recycled.\*

\*Please note that not all parts are recyclable. Recycling of parts is subject to the capabilities of 3rd party suppliers

- 1. Box up your old Dyson.
- 2. Take your packaging to your local post office and send to the address below: Dyson We Recycle Reply Paid 83215

Dyson Service Centre Unit 6 & 7, 7-11 Parraweena Rd

Taren Point, NSW 2229.

#### PRODUCT INFORMATION

Product weight 3.38kg. Please note: Small details may vary from those shown.

# dyson

#### **Dyson Customer Care**

If you have a query about your Dyson fan, call the Dyson Customer Care Helpline with your serial number and details of where and when you bought the fan, or contact us via the Dyson website. The serial number can be found on the base of the product.

#### AU Dyson Customer Care customercare@dyson.com.au

1800 239 766 PO Box 2835.

Taren Point, NSW 2229 Australia www.dvson.com.au

#### NZ Dyson Customer Care dyson@averyrobinson.co.nz 0800 397 667

Avery Robinson Ltd., Unit F, 151D Marua Road, Ellerslie, Auckland 1051, New Zealand www.dyson.co.nz

#### SG Dyson Customer Care singapore@dyson.com 7000 435 7546

Service @ Home Pte. Ltd. 2 Leng Kee Road, #04-09A Thye Hong Centre, Singapore 159086 www.dyson.com.sg

#### ID Dyson Customer Care service@higienis.com 021 707 39766

Permata Plaza Top Floor, TF-04, JI, M. H. Thamrin Kav. 57, lakarta 10350 Indonesia www.dyson.co.id

# www.dyson.com



#### **OPERATING MANUAL**




# **ASSEMBLY** Then twist clockwise Align the arrows. until it clicks and locks. 0 0 0 Now repeat for stage 2.










Your Dyson fan will be covered for parts and labour for 2 years from the date of purchase, subject to the terms of the guarantee.

If you have a query about your Dyson fan, call the Dyson Customer Care Helpline quoting the serial number and details of where/when you bought the fan. The serial number can be found on the rating plate which is on the base of the product.

Most queries can be solved over the phone by one of our Dyson Customer Care Helpline staff (details below).

Visit our website to register your full parts and labour guarantee online (Australia only) www.dyson.com.au/register



For illustration purposes only.

# **IMPORTANT SAFETY INSTRUCTIONS**

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

When using an electrical appliance, basic precautions should always be followed, including the following:

# **△** WARNING

THE FAN AND THE REMOTE CONTROL BOTH CONTAIN

- Pacemakers and defibrillators may be affected by strong magnetic fields. If you or someone in your household has a pacemaker or defibrillator, avoid placing the remote control in a pocket or near to the device.
- Credit cards and electronic storage media may also be affected by magnets and should be kept away from the remote control and the top of the fan.

## **MWARNING**

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- This fan is not intended for use by young children or persons with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction by a responsible person concerning use of the appliance to ensure that they can use the appliance safely.
- Young children should be supervised to ensure that they do not play with the
- The loop amplifier and base plate must be fitted securely before operating this fan. Do not use without the loop amplifier fitted.
- Do not operate any fan with a damaged cable or plug. If the cable or plug is damaged, do not use the fan and contact the Dyson Customer Care Helpline. If the supply cable is damaged, it must be replaced by Dyson, our service agent or similarly auglified persons in order to avoid a hazard.
- If the fan is not working as it should or has been damaged, do not use and contact the Dyson Customer Care Helpline

- Do not run cable under carpeting. Do not cover cable with throw rugs, runners or similar coverings. Arrange cable away from traffic area and where it will not be tripped over.
- Turn off all controls before unplugging. Unplug from outlet when not in use for extended periods. To avoid a tripping hazard, safely coil the cable.
- Do not unplug by pulling on cable. To unplug, grasp the plug, not the cable.
- Suitable for dry locations ONLY. Do not use outdoors or on wet surfaces and do not expose to water or rain.
- 1 0. Do not handle plug or fan with wet hands.
- 1 1. Do not stretch the cable or place the cable under strain. Keep cable away from
- 1 2. Do not put any object into openings or the inlet grille. Do not use with any opening blocked; keep free of dust, lint, hair and anything that may reduce 1 3. Do not use near furnaces, fireplaces, stoves or other high temperature heat
- 1 4. Do not use in conjunction with or directly next to an air freshener or similar
- 1 5. Do not use any cleaning agents or lubricants on this fan. Unplug before cleaning or carrying out any maintenance.
- 1 6. Use only as described in this manual. Do not carry out any maintenance other than that shown in this manual, or advised by the Dyson Customer Care
- 1 7. The use of an extension cable is not recommended.
- 1 8. Always carry the fan by the body, do not carry it by the loop amplifier.

# **READ AND SAVE THESE INSTRUCTIONS**










Do not pull

Do not store near

Do not use near

Do not carry by the

### **3 EASY WAYS TO REGISTER YOUR 2 YEAR GUARANTEE**



Visit our website to register your full parts and labour guarantee online (Australia only).

www.dyson.com.au/register

# REGISTER BY PHONE


Call our dedicated Helpline.


AU 1800 239 766 NZ 0800 397 667 SG 7000 435 7546 ID 021 707 39766




# REGISTER


Complete and return the form to Dyson in the envelope supplied.







## **GUARANTEE FORM**



### **3 EASY WAYS TO REGISTER YOUR 2 YEAR GUARANTEE**

If you do not wish to receive marketing information by these methods from Dyson, please tick this box.



www.dyson.com.au/registe

REGISTER Call our dedicated Helpline. AU 1800 239 766

NZ 0800 397 667

SG 7000 435 7546

ID 021 707 39766

REGISTER

Complete and return the form to Dyson in the envelope supplied.

# dyson

# **AM O2**

# DISASSEMBLY INSTRUCTIONS • INSTRUCCIONES DE DESMONTAJE • DEMONTAGEANLEITUNG • INSTRUCTIONS DE DÉMONTAGE • 保管される際の解体方法

